

INSTALLING THE LED STRIPS IN YOUR 07-13 SPRINTER



What you get: the LED strip, cable, screws, wire ties, & alcohol pad



insert a knife into the slot and carefully pry the existing light away



make a mental note of the colors of the wires and where they connect



connect the new cable as shown in the photo.



decide the location of the LED strip, and wipe the crossbeam with alcohol



peel the orange liner tape and firmly press the LED strip into place on the beam



Test the light by turning the switch on. If the LED doesn't light, swap the yellow connectors.



Next, use the wire ties and the screws to fasten the cable to the beam.



gather up any excess cable and put it behind the OE fixture before snapping it back in.



cyclevan.com
sprinterworld.com
732-238-3110

6 WILLIAM ST. SOUTH RIVER, NJ 08882